### **REO HeNe Lasers**

High-Quality Lasers For Precise Applications And Measurements

Broadest Range of Wavelengths Available







REO is the world leader in high performance HeNe laser manufacturing...

Company Profile

The Research Electro-Optics (REO) legacy is derived from HeNe laser manufacturing. Superior HeNe lasers require the highest quality laser optics. This is what inspired REO's founder, Dr. Robert Knollenberg, to bring optics manufacturing in-house. Today, REO is the world leader in high performance HeNe laser manufacturing, enabled by our unique combination of optics fabrication and expert assembly capabilities.

REO integrates proprietary in-house designed and manufactured laser mirrors into our HeNe lasers. Additionally, REO has provided the majority of mirrors for the HeNe laser industry for the last two decades. REO was also the first company to successfully develop mirrors for volume green HeNe lasers, with their notoriously low gain. Application of our design and optics manufacturing experience developed a unique Frequency and Intensity Stabilized HeNe Laser product. This provides an ideal solution for instrumentation and metrology applications which require long coherence length and high amplitude stability.

In 2018, REO was acquired by Excelitas Technologies<sup>®</sup> Corp. This acquisition has helped support the growth capabilities of the HeNe product line. Today, the REO brand continues to offer the widest range of HeNe wavelengths and highest HeNe powers available on the market.







REO facility in Colorado



R&D Lab on site



Quality inspection on site

### Contents


Company Profile & Timeline	2-3
REO Core Competencies	4
HeNe Lasers vs. Diode Lasers	5
HeNe Offering Specifications	6-7
REO HeNe Advantages	8
Stabilized HeNe Details	9
Tunable HeNe & 30mW HeNe Details	10
OEM Advantages	11



## **REO Core Competencies**



REO fabricates all HeNe mirrors used in our lasers. We also sell our mirrors to other HeNe laser manufacturers.



We manufacture many optical assemblies and have experience with integrating additional assemblies with our HeNe lasers – such as fiber-coupling.

We coat all of the HeNe mirrors we manufacture, enabling us to customize coating specifications via our in-house LDT testing, low absorption coatings, and superpolished surfaces.



REO has many in-house metrology capabilities which ensure the quality of fabrication, thin film deposition, and assembly.



REO HeNe lasers are uniquely suited for a wide range of applications:

- FTIR applications – Narrow/stable linewidth
- Semiconductor Inspection
- Particle Counting
- Metrology
- Alignment
- Raman Spectroscopy
- Research Labs & Universities
- Confocal Microscopy
- Food/Agricultural sorting

- DNA Sequencing
- Flow Cytometry
- Imaging and Medical Equipment
- Opacity Monitoring
- Maritime Visual Guidance Systems
- Hematology
- Polarization Experiments
- Ellipsometry



## HeNe Lasers vs. Diode Lasers

Although both are diodes and Helium-Neon lasers are well-suited for a number of OEM applications, there are some things to take into consideration when making this decision for your application.

Diodes are an extremely versatile product. With a wide variety of wavelengths and a wide range of prices to choose from, they certainly present many options. They are also very small, making them easy to integrate into a product with limited space.

There are, however, several drawbacks:

### **Beam Quality:**

The mode inherent to a diode is elliptical, astigmatic, and highly divergent. These qualities make the beam very difficult to use without a number of correctional optics to compensate. In addition to this, the characteristics of a diode beam can vary within even a single batch of diodes.

Conversely, the beam directly out of a HeNe is fundamentally Gaussian, easily focusable, and very slightly divergent (typically less than 2 mrad). Additional optics can be added to a diode to mimic these qualities but this adds not only additional cost and assembly time, it also adds more points of potential failure.

Parameter	HeNe	Diode
Best Beam Quality	✓	
Narrowest Linewidth	~	
Highest Output Power		<ul> <li>✓</li> </ul>
Smallest Device Size		~
Longest Lifetime	~	
Variety/tunability of Frequencies		~
Robustness Against Retro-reflection	~	
Lowest Cost	~	



### Wavelength Bandwidth/Stability:

The bandwidth of a laser diode is also very wide – on the order of several nanometers. To stabilize a diode is a costly process but it can be done with enough effort.

By comparison, wavelength stability is inherent to a HeNe. The bandwidth of an unstabilized HeNe is on the order of a few GHz, ~1000 times than that of a diode. A stabilized HeNe is ~100 times better than that.

### **Robustness:**

Diodes are very sensitive to ESD and radiation. They can also be damaged by optical feedback.


HeNe's are inherently robust to radiation, ESD, and optical feedback.

### **Inter-Cavity Access:**

HeNe's also allow access to inner cavity power, which is useful for particle counting applications.

### Wavelength Standard:

The HeNe wavelength is an atomic reference. The transition of Neon is well-enough known that the HeNe is used as a standard to measure against.




# HeNe Specifications


Wavelength (nm)	Power (mW)	Polarization	Mode Structure	Beam Diameter (mm)	Beam Divergence (mrad)	Longitudinal Mode Spacing (MHz)	Lo Be (
Green HeNe Laser Systems							
543 (multimode)	0.5	Linear, > 500:1	Multimode	1.62	4.02	566	
543	0.5	Random	TEM <sub>00</sub> > 99%	0.64	1.07	566	
543	0.5	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.72	0.96	415	
543	1.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.83	0.84	303	
543	1.0	Random	TEM <sub>00</sub> > 99%	0.70	0.98	441	
543	1.5	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.83	0.84	303	
543	2.0	Random	TEM <sub>00</sub> > 99%	0.83	0.84	303	
Yellow HeNe Laser Systems		•			•	·	
594	1.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.74	1.03	416	
594	2.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.74	1.03	416	
Red HeNe Laser Systems						<b>^</b>	
633	0.5	Random	TEM <sub>00</sub> > 99%	0.57	1.41	1082	
633	0.8	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.57	1.41	1082	
633	1.5	Random	TEM <sub>00</sub> > 99%	0.57	1.41	1082	
633	1.5	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.64	1.25	714	
633	2.0	Random	TEM <sub>00</sub> > 99%	0.81	1.00	566	
633	2.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.81	1.00	566	
633	3.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.70	1.20	633	
633	5.0	Random	TEM <sub>00</sub> > 99%	0.80	1.01	441	
633	5.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.80	1.01	441	
633	12.0	Random	TEM <sub>00</sub> > 99%	0.88	0.92	316	
633	12.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.88	0.92	316	
633	17.0	Random	TEM <sub>00</sub> > 99%	0.98	0.82	252	
633	17.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.98	0.82	252	
633	30.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	1.22	0.66	163	
Stabilized Red HeNe Laser Syst	tems						
633	1.5	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.7	1.2		
Infrared HeNe Laser Systems		-	<del>.</del>				
1152	1.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	1.09	1.34	375	
1523	1.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	1.36	1.43	316	
3390	2.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	2.02	2.13	316	
Dual Line HeNe Laser Systems						•	
1523/633	0.8/1.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	1.36/0.87	1.42/0.82	316	
1152/3390	2.0/3.0	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.90/1.55	1.62/2.78	316	
Tunable HeNe Laser Systems	r	r	· · · · · · · · · · · · · · · · · · ·		r	r	
633	4.0			0.77	1.05		
612	2.5			0.76	1.03		
604	0.5	Linear, > 500:1	TEM <sub>00</sub> > 99%	0.75	1.02	428	
594	0.6			0.74	1.02		
543	0.3			0.71	0.97		




ng Term am Drift mrad)	"Noise (30Hz – 10MHz)" RMS	Laser Head Weight (g)	Dimensions (Ø x L) mm	CRDH/CE Classification	REO Model	Replacement Head PN	Recommended Power Supply
< 0.02	< 1%	600	44.5 x 330.2	IIIa/3R	40141	30683	39783
< 0.05	< 1%	600	44.5 x 330.2	IIIa/3R	30967	30605	39783
< 0.05	< 1%	650	44.5 x 425.5	IIIa/3R	30968	30682	39783
< 0.05	< 1%	750	44.5 x 533.4	IIIa/3R	39581	30526	39784
< 0.05	< 1%	650	44.5 x 533.4	IIIa/3R	39568	30532	39783
< 0.05	< 1%	750	44.5 x 533.4	IIIa/3R	33361	32656	39784
< 0.05	< 1%	750	44.5 x 533.4	IIIa/3R	30972	30609	39784
. 0.05	10/	650	44 E 42E E	III (2D	4000.4	20571	20702
< 0.05	< 1%	650	44.5 x 425.5	IIIa/3R	40094	30571	39783
< 0.05	< 1%	650	44.5 x 425.5	IIIa/3R	39582	30639	39783
< 0.05	< 5% S	600	44.5 x 177.8	IIIa/3R	31008	39698	39783
< 0.05	< 5%	600	44.5 x 177.8	IIIa/3R	31007	39697	39783
< 0.05	< 5%	600	44.5 x 177.8	IIIa/3R	31005	30404	39783
< 0.05	< 1%	600	44.5 x 241.3	IIIa/3R	30025	30028	39783
< 0.05	< 1%	600	44.5 x 330.2	IIIa/3R	30988	30629	39783
< 0.05	< 1%	600	44.5 x 330.2	IIIa/3R	30989	30621	39783
< 0.05	< 1%	600	44.5 x 346.1	IIIa/3R	14354	14353	39783
< 0.05	< 1%	650	44.5 x 425.5	IIIa/3R	30990	30630	39783
< 0.05	< 1%	650	44.5 x 425.5	IIIa/3R	30991	30623	39783
< 0.05	< 1%	750	44.5 x 533.4	IIIa/3R	30992	30633	39785
< 0.05	< 1%	750	44.5 x 533.4	IIIa/3R	30993	30624	39785
< 0.04	< 1%	840	44.5 x 660.4	IIIa/3R	39635	30635	39786
< 0.05	< 1%	840	44.5 x 660.4	IIIa/3R	30995	30625	39786
< 0.05	< 1%	6939	1069 x 95.25 x 95.25	IIIa/3B	16194	Integrated	Integrated
	1		44 5 - 201 0	III.a / 2 D	22724	22722	22722
		<u> </u>	44.5 x 381.0	IIIa/3R	32734	32732	32733
< 0.02	< 5%	853	44.5 x 533.4	IIIa/3B	40136	30684	39785
< 0.02	< 5%	853	44.5 x 533.4	IIIa/3B	33141	30612	39785
< 0.05	< 5%	750	44.5 x 533.4	IIIa/3B	32172	30685	39785
	1	[		<b></b>			
< 0.05	< 20%	750	44.5 x 533.4	IIIa/3B	40137	30538	39785
< 0.05	< 20%	750	44.5 x 533.4	IIIa/3B	40138	30615	39785
< 0.05	< 1%	5000	450.8 x 100.0 x 120.7	IIIb	30602 (115 V input) 30603 (230 V input)	Integrated	Integrated











### REO HeNe Laser Advantage

REO has the broadest range of HeNe wavelengths commercially available. Our low-defect surfaces provide unparalleled beam quality and allow our lasers to lase at low gain transitions, giving REO the widest range of HeNe wavelengths available.

REO HeNe tubes are made of mostly stainless steel as opposed to the traditional, all-glass tube, providing a number of advantages.



#### He Ne visible laser lines




# Stabilized HeNe Details



REO offers the highest power stabilized HeNe on the market at 1.5mW. This is made possible by our patented optical configuration which uses a non-normal incidence birefringent optical component rather than a non-mode-hopping mirror.

Our configuration is both lower loss than this non-mode-hop mirror and also results in the polarization being fixed relative to the tube's geometry, making the tube easier to install without having to determine the polarization direction in the first place. Our stabilized HeNe laser can also be customized for use in an OEM application. Please contact us to discuss how this product can be best modified to suit your needs.






# Tunable HeNe Details

The Line-Tunable HeNe Laser generates 500:1 linearly polarized outputs of five independent line-selectable wavelengths: 543 nm, 594 nm, 604 nm, 612 nm, and 633 nm. Each of these wavelengths can be individually selected by tuning the Littrow prism at the end of the laser via a micrometer adjustment.


This product is a tremendous value for any application that requires multiple wavelengths but not necessarily multiple lasers, such as research labs or educational institutions.



### 30mW HeNe Details

REO also offers the highest power 633nm HeNe on the market. The 16194 Red HeNe Laser generates a 500:1 linearly polarized output of 30.0 mW (minimum) at 633 nm. Longitudinal mode frequency is approximately 163 MHz. Utilizing enhanced designs and superior optical components this HeNe laser delivers unsurpassed operational stability and lifetime. The mirror quality and performances are optimized to result in the highest quality HeNe laser available in the market.

For this model, the power supply is integrated into the housing design and automatically configures for use with either 110V or 220V, making the system as compact as possible.





www.reohenelasers.com

# **REO OEM Advantages**



Our unique metal body design makes our HeNe lasers uniquely suited for OEM applications.

We can directly attach any optical assemblies (telescopes, periscopes, fiber-coupling) to the body of our laser, rather than just the housing, allowing for a more stable pointing solution.

Our HeNe's were developed with an OEM application in mind. Due to the need for flexibility and the tight space constraints of this application, we decided to depart from the traditional all-glass tube in favor of a mostly metallic one, allowing us to safely mount the laser directly into the machining without any additional housing.

Our lasers also have lower rates of helium diffusion due to our metallic housing. This means that field replacements are less frequently required, easing the service burden on an equipment manufacturer.

The REO HeNe laser team is committed to providing the best OEM solution for your application. Both our lasers and our qualification procedures can be modified to meet your specific requirements, so that there is no need to compromise with a product that is less than ideal.





### **About Excelitas Technologies**

Excelitas Technologies<sup>®</sup> Corp. is a photonics technology leader focused on delivering innovative, high-performance, market-driven solutions to meet the lighting, optronics, detection and optical technology needs of our OEM customers. Serving a vast array of applications across biomedical, scientific, safety, security, consumer products, semiconductor, industrial manufacturing, defense and aerospace sectors, Excelitas stands committed to enabling our customers' success in their end-markets. Our photonics team consists of 7,000 professionals working across North America, Europe and Asia, to serve customers worldwide.





www.reohenelasers.com henelasers@reoinc.com

#### For a complete listing of our global offices, visit www.excelitas.com/locations

© 2020 Excelitas Technologies Corp. All rights reserved. The Excelitas logo and design and product trademarks are registered trademarks of Excelitas Technologies Corp. Excelitas reserves the right to change this document at any time without notice and disclaims liability for editorial, pictorial or typographical errors.