C30737MH Series – Silicon Avalanche Photodiodes (APD) in LLC SMD package APD for High Volume LiDAR, Range Finding and Laser Meters





Excelitas' C30737MH-230 and C30737MH-500 series Avalanche Photodiodes are high speed, low breakdown voltage APDs that provide low noise and high responsivity, optimized for wavelengths of 800 nm or 900 nm. These Photodiodes are mounted inside an ultra-compact 1.75mm x 2 mm SMD package.

Key Features

- Spectral response 500 nm 1100 nm
- High Responsivity at 800 nm and 900 nm
- Low Noise 0.1 pA/VHz
- Large active area diameter of 230 μm and 500 μm
- Ultra Compact SMD Package (1.75 mm x 2 mm)
- Tape and Reel packaging
- RoHS compliant

Applications

- LiDAR / ToF measurements
- Laser range finding
- Speed measurements
- Optical communication systems
- 3D Laser scanning
- Gesture Recognition

All specifications are referring to an ambient temperature of $T_A = 22$ °C and a voltage V_{OP} that operates the APD at a Gain of M = 100, unless otherwise specified.

Table 1: Key parameters

Parameter	Symbol	Minimum	Typical	Maximum	Unit
Breakdown Voltage¹	V_{BD}	120		260	V
Spectral Range	Δλ	500		1100	nm
Recommended Operating Gain ²	M		100		

Note 1: Breakdown Voltage binning available. Refer to Table 2.

Note 2: For further information on the usage at different gains, please contact our experts at Excelitas Technologies.



APD for High Volume LiDAR, Range Finding and Laser Meters

Table 2: Ordering Information

Parameter	C30737MH	- ###	- ##	X
EPI APD	X			
Ultra Compact LLC SMD package	X			
Circular Active Area	Х			
230 μm useful diameter		230		
500 μm useful diameter		500		
Optimized for 800 nm			80	
Optimized for 900 nm			90	
$V_{BD} = 120 - 160 V^{1,3,4}$				Α
$V_{BD} = 160 - 200 \text{ V}^1$				В
$V_{BD} = 180 - 220 V^{2,3,5}$				С
$V_{BD} = 220 - 260 \text{ V}^2$				D
No V _{BD} binning				N

Note 1: Binning A and B are available for 800 nm optimized APDs (C30737MH-230-80X, C30737MH-500-80X).

Note 2: Binning C and D are available for 900 nm optimized APDs (C30737MH-230-90X, C30737MH-500-90X).

Note 3: Bandwidth tends to be lower for lower breakdown voltage bins. Please contact our experts at Excelitas Technologies for further information.

Note 4: Bins A and B may overlap by 2 V.

Note 5: Bins C and D may overlap by 5 V.

Table 3: Absolute Maximum Ratings

Parameter	Symbol	Condition	Value	Units
Forward Current		RMS		m A
- Forward Current	IF	Single Peak, 1 s	50	mA
Total Power dissipation	P _{tot}		2	mW
Deviana Cumant	I-	RMS	5	
Reverse Current	I _R	Single Peak, 10 ns	400	μΑ
Payarca Current Dancity		RMS	0.1	mA/mm ²
Reverse Current Density	J_R	Single Peak, 10 ns	10	IIIA/IIIIII-
Storage Temperature	Ts		-50 100	°C
Operating Temperature	T _{Op}		-40 85	

Note 1: Stresses above those listed under "Absolute Maximum Ratings" may cause permanent damage to the device.

Note 2: Exposure to absolute maximum rating conditions for extended periods may affect device reliability.

APD for High Volume LiDAR, Range Finding and Laser Meters

Table 4: Optical Specifications C30737MH-230-80 / C30737MH-500-80

Parameter	Symbol	Minimum	Typical	Maximum	Unit
Peak Responsivity	λ_{peak}		800		nm
Responsivity @λ = 800 nm	R		50		A/W
Quantum Efficiency @ λ = 800 nm ¹	QE		78		%
Rise Time / Fall Time ²	t _r / t _f		0.3		ns
Bandwidth	f _{3dB}		1.3		GHz

Table 5: Optical Specifications C30737MH-230-90 / C30737MH-500-90

Parameter	Symbol	Minimum	Typical	Maximum	Unit
Peak Responsivity	λ_{peak}		900		nm
Responsivity @λ = 900 nm	R		60		A/W
Quantum Efficiency $@\lambda = 900 \text{ nm}^1$	QE		83		%
Rise Time / Fall Time ²	t _r / t _f		0.9		ns
Bandwidth	f _{3dB}		400		MHz

Note 1: Quantum Efficiency is not a directly measurable quantity. The above specified typical parameter is linked to the typical responsivity by $QE=rac{1240\,R}{\lambda M}$. Note 2: As estimated by $t_{r/f}=rac{0.35}{f_{3dB}}$.

APD for High Volume LiDAR, Range Finding and Laser Meters

Table 6: Electrical Specifications C30737MH-230-80 / C30737MH-500-80

Parameter	Symbol	Minimum	Typical	Maximum	Units
Breakdown Voltage	V_{BD}	120		210	V
Temperature Coefficient of V _{BD}	ΔV/ΔΤ		0.5		V/°C
Capacitance	C ₂₃₀		1		pF
	C ₅₀₀		2		
Dark Current ¹	i _{D,230}		0.05	0.5	nA
	i _{D,500}		0.1	1	
Dark Noise ²	i _N		0.1		pA/√Hz
Noise Equivalent Power ³	NEP		2.0		fW/√Hz

Table 7: Electrical Specifications C30737MH-230-90 / C30737MH-500-90

Parameter	Symbol	Minimum	Typical	Maximum	Units
Breakdown Voltage	V_{BD}	180		260	V
Temperature Coefficient of V _{BD}	ΔV/ΔΤ		1.3		V/°C
Capacitance	C ₂₃₀		0.6		nΕ
	C ₅₀₀		1		pF
Dark Current ¹	i _{D,230}		0.05	0.5	- nA
	i _{D,500}		0.1	1	
Dark Noise ²	i _N		0.1		pA/√Hz
Noise Equivalent Power ³	NEP		1.7		fW/√Hz

Note 1: Surface (i_{DS}) and bulk (i_{DB}) dark current are contributing to the total dark current by $i_D = i_{DS} + i_{DB}M$. Note 2: Due to the natural fluctuations of amplified charge carriers the APD will also generate noise when not illuminated. Since the noise characteristics and hence the signal-to-noise ratio (SNR) are dependant on the bandwidth (B) and operating wavelength (λ) inside the final system the illuminated noise

$$i_{ill} = \sqrt{2qB[i_{DS} + (i_{DB}M^2 + R_0(\lambda)M^2P)F]}$$

needs to be considered. Hence the SNR is defined as:


$$SNR = \frac{i_P^2}{i_{III}^2} = \frac{(PR_0(\lambda)M)^2}{i_{III}^2}$$

with P the incident optical power in W, $R_0(\lambda)$ the intrinsic (M = 1) responsivity in A/W, q the charge carrier and an excess noise factor of typical 6.9 for silicon materials.

Note 3: The NEP is specified in dark conditions and gain of M = 100 as $NEP = \frac{i_N}{R(\lambda)}$

APD for High Volume LiDAR, Range Finding and Laser Meters

Figure 1: APD Package Dimensions C30737MH Series



APD for High Volume LiDAR, Range Finding and Laser Meters

Figure 2: Typical Responsivity




Figure 3: Typical Gain vs. Operating Voltage




Figure 4: Typical Capacitance vs. Operating Voltage






Figure 5: Typical Dark current vs. Ambient Temperature



APD for High Volume LiDAR, Range Finding and Laser Meters

Figure 6: Tape and Reel Packing Specification



APD for High Volume LiDAR, Range Finding and Laser Meters

Information

Excelitas Technologies' C30737MH series silicon avalanche photodiodes (APD) provide high responsivity between 500 nm and 1100 nm, as well as extremely fast rise times at all wavelengths with a cut-off frequency > 1 GHz for some versions.

The APDs are available in standard sizes of 230 μ m and 500 μ m diameter. The diodes are mounted on a FR4 substrate leadless laminate carrier (LLC) for surface mount assembly. The encapsulation material is an epoxy resin for cost efficient and high-volume manufacturing.

The package design and assembly processing techniques are such that the die positioning is well controlled to the reference surfaces. This aids in the alignment of optical elements to the package and is superior to many of the commercially available plastic lead frame TO packages.

Testing methods

Excelitas verifies the electro optical specifications on every device. Visual inspection during fabrication is performed as per our quality standards.

Excelitas Technologies is certified to meet ISO-9001.

Packaging and shipping

All C30737MH APDs are supplied in tape and reel for quantities of 3000 units per reel; as shown in Figure 6. For sampling quantities the APDs are shipped in Gel Pack packages.

Storage and handling

Excelitas highly recommends to follow the below guidelines:


- Keep devices in an ESD controlled environment until final assembly.
- Keep Tape & Reel package closed until final assembly.
- Remove Devices from Tape & Reel by using a vacuum pick-up tool.
- If a manual picking method is necessary, use a vacuum pick or non-metallic tweezer.

APD for High Volume LiDAR, Range Finding and Laser Meters

Table 8: Reflow Solder Profile

The following reflow solder profile is a typical used profile for SAC305 solder alloys. Specific solder parameters depend on the solder alloy used.

Profile Feature	Symbol	Typical	Units
Minimum Sparkling Temperature	T_{Smin}	150	°C
Maximum Sparkling Temperature	T_{Smax}	200	°C
Sparkling Time	t_{S}	75	S
Minimum Reflow Temperature	TL	217	°C
Peak Temperature	T_P	244	°C
Reflow Time	t∟	65	S
Time within T _P - 5°C	t_{P}	25	S
Ramp Down Rate	ΔT_c	2	°C/s



MSL rating

The series of PIN diodes comply with a moisture sensitivity level (MSL) rating of 2A as defined in IPC/JEDEC-J-STD-033C. This allows for up to 4 weeks floor life at \leq 30 °C / 60% RH once removed from the sealed reel packaging. For complete details refer to the IPC/JEDEC-J-STD-033C specification.

APD for High Volume LiDAR, Range Finding and Laser Meters

RoHS Compliance

This series of APD diodes are designed and built to be fully compliant with the European Union Directive on restrictions of the use of certain hazardous substances in electrical and electronic equipment.



Warranty

A standard 12-month warranty following shipment applies. Any warranty is null and void if the photodiode window has been opened.

About Excelitas Technologies

Excelitas Technologies is a global technology leader focused on delivering innovative, customized solutions to meet the lighting, detection and other high-performance technology needs of OEM customers.

Excelitas has a long and rich history of serving our OEM customer base with optoelectronic sensors and modules for more than 45 years beginning with PerkinElmer, EG&G, and RCA. The constant throughout has been our innovation and commitment to delivering the highest quality solutions to our customers worldwide.

From aerospace and defense to analytical instrumentation, clinical diagnostics, medical, industrial, and safety and security applications, Excelitas Technologies is committed to enabling our customers' success in their specialty end-markets. Excelitas Technologies has approximately 7,000 employees in North America, Europe and Asia, serving customers across the world.

Excelitas Technologies

22001 Dumberry Road Vaudreuil-Dorion, Quebec Canada J7V 8P7 Telephone: (+1) 450.424.3300 Toll-free: (+1) 800.775.6786 Fax: (+1) 450.424.3345 Excelitas Technologies GmbH & Co. KG Wenzel-Jaksch-Str. 31 D-65199 Wiesbaden Germany Telephone: (+49) 611 492 430

Fax: (+49) 611 492 165

Excelitas Technologies Singapore, Pte. Ltd. 8 Tractor Road Singapore 627969 Telephone: (+65) 6775 2022 (Main number) Telephone: (+65) 6770 4366 (Customer Service)

Fax: (+65) 6778-1752



Contact us at http://www.excelitas.com/contact

For a complete listing of our global offices, visit www.excelitas.com/locations

© 2021 Excelitas Technologies Corp. All rights reserved. The Excelitas logo and design are registered trademarks of Excelitas Technologies Corp. All other trademarks not owned by Excelitas Technologies or its subsidiaries that are depicted herein are the property of their respective owners. Excelitas reserves the right to change this document at any time without notice and disclaims liability for editorial, pictorial or typographical errors.